


## Global Dispenser Instructions for use with ROZALEX GAUNTLET 5 Litre Cartridge

### GLOBAL DISPENSER MODEL 164851

Discharge: 4ml per stroke or  
2ml per stroke with  
Restrictor Spacer Fitter



#### CONTENTS

- A... Pump/Bottle Housing (Assembly)
- B... Support Bracket
- C... Refill Housing Retaining Screw
- D... Allen Key
- E... Fixing Screws (4)
- F... Wall Flags (4)
- G... Restricted Output Pump Spacer

#### FIXING INSTRUCTIONS

1. Detach Pump/Bottle Housing (A) from Support Bracket (B) by loosening Retaining Screw (C) with Allen Key (D)
2. Fix Support Bracket (B) to wall with Screws (E) and Wall Plugs (F)

Note; Ensure correct alignment after fixing the first of the upper wall plugs by re-fitting the refill housing and placing a spirit level across the top.

3. To fill refill bottle to Pump/Bottle Housing (see separate instructions on bottle top)
4. Fit Pump Spacer (G) for Restricted output.

Call +44 1798 874 268 for any clarification